



## CONFINED AREA PROCEDURE

### WIND DIRECTION

Wind direction

### POWER CHECKS

Near area and into wind

Minimum power · 40kts / 20"

Maximum power · Full throttle / 28"

### ORBIT

55-60 kt / 500 ft / Right pattern

#### High Recon

- Shape
- Size
- Surface
- Slope
- Safety
- Spot
- Sun
- Surrounds

Longest axis / Route in / Route out  
Can we fit / Approach / Departure  
Power info  
Assume slope  
Describe  
Recirculation

#### Low Recon

- Checks on cross wind
- Confirm observations
- Comittel point · Dummy approach or not