



CONFINED AREA PROCEDURE

WIND DIRECTION

Wind direction

POWER CHECKS

Near area and into wind

Minimum power · 40kts / 20"

Maximum power · Full throttle / 28"

ORBIT

55-60 kt / 500 ft / Right pattern

High Recon

- Shape
- Size
- Surface
- Slope
- Safety
- Spot
- Sun
- Surrounds

Longest axis / Route in / Route out
Can we fit / Approach / Departure
Power info
Assume slope
Describe
Recirculation

Low Recon

- Checks on cross wind
- Confirm observations
- Comittel point · Dummy approach or not