



LIMITED POWER

POWER CHECKS FOR TAKE-OFF

2 ft Hover - Note MAP
Full power - Note MAP

POWER MARGIN FOR TAKE-OFF

< 1" - Running Take-Off
> 1" - Cushion-Creep Take-Off
1-2" - Towering Take-Off
> 3" - Vertical Climb OGE

POWER CHECKS FOR LANDING

40 kts at 2650 RPM with Carb Heat - Note MAP
Full power - Note MAP

POWER MARGIN FOR LANDING

< 2" - Run-On Landing
2-3" - Zero Speed Landing
4" - Approach to Low Hover
6-8" - Hover OGE